

## Test the signal strength of an ADC-W115C

Verify the normalized signal strength of the ADC-W115C using the Partner Portal or MobileTech app.

### To test the signal strength of the ADC-W115C

#### To test the signal strength of the ADC-W115C using the Partner Portal: ^

1. Log into the Partner Portal.
2. Find the customer account.
3. Click **Equipment**.
4. Click **Access Points**.
5. Click to selected the desired access point.
6. In *Device Information*, click to expand the desired access point.
7. In *Normalized Signal Strength*, click ↻.

#### To test the signal strength of the ADC-W115C using the MobileTech app: ^

1. Log into the MobileTech app.
2. Find the customer account.
3. Tap **Equipment**.
4. Tap the name of the desired access point.
5. Tap **Check Signal Strength**. A new page opens with the normalized signal strength percentage.

